



100% Cotton Sunshade Instructions for Installation

1. Peel the paper off the sunshade's three adhesive-backed Velcro® strips.
2. With the strips still attached to the sunshade, apply the three adhesive-backed strips to the inside of the hat or cap.
3. Make sure that:
 - The sunshade is centered at the back of hat or cap so it hangs down to both shoulders (see photo).
 - The entire sunshade hangs behind the headband so that it does not interfere with helmet.



Americas:

E.D. Bullard Company
1898 Safety Way
Cynthiana, KY 41031-9303
Toll free: 877-BULLARD (285-5273)
Tel: 859-234-6616
Fax: 859-234-8987
www.bullard.com

Europe:

Bullard GmbH
Lilienthalstrasse 12
53424 Remagen • Germany
Tel: +49-2642 999980
Fax : +49-2642 9999829
www.bullardextrem.com

Asia-Pacific:

Bullard Asia Pacific Pte. Ltd.
LHK Building
701, Sims Drive, #04-03
Singapore 387383
Tel: +65-6745-0556
Fax: +65-6745-5176
www.bullard.com



The Bullard three-rib design
is a registered trademark
of the E.D. Bullard Company.



©2011 Bullard. All rights reserved.
Velcro is a registered trademark of Velcro USA.

6022500001B(0411)