

# Service Kit for ADP Series (Air Motor Service Only Kit)

1/2" NPT Female

Pipe connection

## **NOTE:**

This kit contains parts for servicing of the <u>air-drive-</u> <u>motor</u> only- (Bullard Part No. 17761).

# 17761 Kit Contains (See Reference Numbers on Drawings.)

- 4 Composition vanes (4)
- 4 Vane springs (5)
- 2 Push pins (6)
- 1 Drive end bearing (7)
- 1 Dead end bearing (8)
- 1 Shaft seal (11)
- 2 Body gaskets (13)
- 1 O-Ring (15)
- 1 End cap gasket (17)

#### General

This air motor is precision built. The top clearance between ROTOR and BORE is .0015". End clearance between sides of rotor and end plates is .0035".

The 4 vanes take-up their own wear and will last 5,000 to 10,000 hours with proper use and maintenance:

- a. Use of Bullard's Micro-mist lubricator-adjusted to approximately 1-drop of recommended oil/minute.
- b. Properly adjusted INLET pressure 80 to 110 psig range.
- c. Correct operating speed as determined by monitoring OUTLET pressure 5 to 20 psig range.
- d. Leaving lubricated during shut-down periods.

### Vane Replacement

An experienced mechanic may accomplish this easily:

- 1. Remove outboard end plate (2) (opposite the drive shaft end). Use a PULLER TOOL. Do not pry with screwdriver this will dent the end plate and body causing leaks.
- 2. Clean chamber and rotor with approved solvents only.\*
- 3. Lubricate chamber with a squirt of oil.
- Install new vanes with the NOTCHED EDGE towards the bottom of the slot.

### 

NOTE

Pump Compressor Repair Kit for ADP Pumps is Bullard Part No. 15922.

#### **Bullard Center**

2421 Fortune Drive Lexington, KY 40509 • USA 877-BULLARD (285-5273) Tel: +1-859-234-6616 Fax: +1-859-246-0243 Americas: E.D. Bullard Company 1898 Safety Way Cynthiana, KY 41031-9303 877-BULLARD (285-5273) Tel: 859-234-6616 Fax: 859-234-8987

#### Europe: Bullard GmbH Dieselstrasse 8a


53424 Remagen • Germany Tel: +49-2642 999980 Fax: +49-2642 9999829

# www.bullard.com

Bullard Asia-Pacific Pte. Ltd. 51 Changi Business Park Central 2 #03-04 The Signature Singapore 486066 Tel: +65 6745 0556 Free-Air i



©2023 Bullard. All rights reserved. Free-Air is a registered trademark of Bullard.



### **Complete Rebuild**

1/2" NPT Female

Pipe connection

- 1. Remove all piping from Air Motor.
- 2. Remove MOTOR GUARD.
- 3. Disconnect WOOD'S coupling (Allen screws).
- 4. Remove Air Motor from housing.
- 5. Replace all items provided in kit (bearings, seals, gaskets, etc.)
- \* Recommended solvents: Cleaning Solvent available as Bullard Part No. S17931,- GAST AH255HD SAFETY SOLVENT.

California Proposition 65 A WARNING Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

6093500205D (1123)